



TECHMARK, INC.

technology from the ground up

5801 W. Mt. Hope Hwy. Lansing, MI 48917
ph (517) 322 0250 fax (517) 322 0470
techmark@techmark-inc.com www.techmark-inc.com

Using Windows ActiveSync to transfer Techmark's IRD Data Sets from the iPAQ to your personal computer. All iPAQ's are preprogrammed and tested prior to shipping



1. At your personal computer (pc), close all Windows programs and insert the supplied CD that contains the current ActiveSync software. The software should automatically run; click on "Start Here" and follow instructions.
*****Do NOT connect cradle to pc yet, you will be prompted later to do so*****
2. On the left side column, click on "Install ActiveSync" to allow the pc and iPAQ to communicate.
3. Read the information provided and click on "Install". It is best to use the defaults provided when prompted.
4. When prompted, connect the iPAQ cradle to the pc via USB only and click on the corresponding selection.
5. The software will prompt you to set up a partnership and you should select "Yes, Synchronize with this computer".
6. On the "Select Synchronization Settings" dialog, uncheck all items. Then check the "Files" box, and click the OK button when asked if you want to create a synchronization folder on you pc. This folder will allow the pc to recieve the PocketIRD impact data sets copied to C:\MyDocuments\IRDPocketPC My Documents. For Windows 2000 & XP, files are copied to C:\Documents and Settings*userID*\My Documents\IRDPocketPC My Documents where *userID* is the user name you use for logon.
***** "Files" is the only synchronize options be used for the PocketIRD *****
7. Close ActiveSync and "Start Here" windows using the "X" in the top right corner, and remove cd from pc.
8. With the iPAQ still in its cradle, open the "IRDPocketPC My Documents" folder using the desktop icon. Right-click on the "CopyIRD", choose "Send To" and then "Desktop (create shortcut)".
9. Double-click on the "Shortcut to CopyIRD" desktop icon to copy the IRD impact files from the "IRDPocketIRD My Documents" folder to the folder used by the PCIRD software. The data sets can now be viewed, edited, and printed via your pc using the PCIRD software. Repeat this step everytime you want to copy new IRD impact data files to the PCIRD folder for further analysis using the PCIRD software.

Congratulations, you just mastered the Techmark PocketIRD File Transfer System!

If at anytime the iPAQ "freezes" or "locks up", use stylus to press reset button on bottom of iPAQ to the right of the connector.