



Alarm Pro Administrator Usage

Overview: Updated 2/19/2020


A new version of Alarm Pro has been integrated into the StorTrac and SporTrac software. Farm administrators will have the ability to manage which bins or rooms will have alarms assigned to them, as well as which users will get those alarms. In addition to this, farm admins will be able to change the frequency in which alarms are sent out. The purpose of this standard operating procedure (SOP) is to guide farm admins through the process of setting up Alarm Pro user settings, as well as adjusting the frequency of Alarm Pro alerts.

Adjusting Alarm Pro User Settings

1) Begin by pressing the “Settings” button shown in the red box.




2) Once in the settings, press “View Users”.





Alarm Pro Administrator Usage




3) Find a user you would like to assign or modify Alarm Pro settings for by click on the “Edit” button next to their name.

Name: Test, Demo Farms: Techmark-20 ⓘ 

Email: demotest@techmark-inc.com

4) Scroll down to the “User Access” section and press the blue “+” sign next to the company name to expand it.

User Access ⓘ

 Techmark, Inc. [company]  View  Change

5) Press the blue “+” again to expand the farm view.

User Access ⓘ

 Techmark, Inc. [company]  View  Change

 Techmark Engineering [farm]  View  Change

 Techmark-20 [farm]  AlarmPro  View  Change



Alarm Pro Administrator Usage

6) The green arrow shows which bins or rooms are enabled to receive Alarm Pro alerts from and a red X shows when they are disabled. Press the Alarm Pro button next to the bin or room name to toggle.

User Access

[-] Techmark, Inc. [company]	<input checked="" type="checkbox"/> AlarmPro	<input checked="" type="checkbox"/> View	<input checked="" type="checkbox"/> Change
Techmark Engineering [farm]	<input checked="" type="checkbox"/> AlarmPro	<input checked="" type="checkbox"/> View	<input checked="" type="checkbox"/> Change
[-] Techmark-20 [farm]	<input checked="" type="checkbox"/> AlarmPro	<input checked="" type="checkbox"/> View	<input checked="" type="checkbox"/> Change
Bin 1 [unit]	<input checked="" type="checkbox"/> AlarmPro	<input checked="" type="checkbox"/> View	<input checked="" type="checkbox"/> Change
Bin 2 [unit]	<input checked="" type="checkbox"/> AlarmPro	<input checked="" type="checkbox"/> View	<input checked="" type="checkbox"/> Change

7) When the Alarm Pro button next to the Farm Name is green, it indicates that every bin in that farm is enabled. When it's a grey box, it indicates that there is a combination of enabled and disabled bin alerts.

User Access

[-] Techmark, Inc. [company]	<input checked="" type="checkbox"/> AlarmPro	<input checked="" type="checkbox"/> View	<input checked="" type="checkbox"/> Change
Techmark Engineering [farm]	<input checked="" type="checkbox"/> AlarmPro	<input checked="" type="checkbox"/> View	<input checked="" type="checkbox"/> Change
[-] Techmark-20 [farm]	<input type="checkbox"/> AlarmPro	<input checked="" type="checkbox"/> View	<input checked="" type="checkbox"/> Change
Bin 1 [unit]	<input checked="" type="checkbox"/> AlarmPro	<input checked="" type="checkbox"/> View	<input checked="" type="checkbox"/> Change
Bin 2 [unit]	<input checked="" type="checkbox"/> AlarmPro	<input checked="" type="checkbox"/> View	<input checked="" type="checkbox"/> Change



Alarm Pro Administrator Usage

8) You can click on this farm Alarm Pro button to toggle every bin in that farm for quick management.

The image displays two screenshots of a 'User Access' interface. The top screenshot shows a list of entities: 'Techmark, Inc. [company]', 'Techmark Engineering [farm]', 'Techmark-20 [farm]', 'Bin 1 [unit]', and 'Bin 2 [unit]'. Each entity has 'View' and 'Change' buttons. The 'AlarmPro' button for 'Techmark-20 [farm]' is highlighted with a red box and contains a red 'X'. The bottom screenshot shows the same interface, but the 'AlarmPro' button for 'Techmark-20 [farm]' now contains a green checkmark, indicating it has been toggled on.




Alarm Pro Administrator Usage

9) When you are done adjusting the user settings make sure you scroll down and hit “Save Changes”.



10) When the settings have been saved, scroll up to the top and press “Exit Settings”.







Alarm Pro Administrator Usage

Adjusting Alarm Pro Alert Frequency


1) Press on the gear icon on your farm's banner to get to the farm's settings



2) Press on "Alarm Pro" settings



3) From here you can change the frequency of alerts and see the list of users and their emails



Questions?

For questions, concerns, or suggestions, please email or call:

seffa@techmark-inc.com

517-322-0250